



**Recommendations**

- Set up and operate only under the direction and supervision of qualified personnel.
- Operator should be experienced in the safe operation and handling of high pressure jacking systems.
- Ensure track is setup and remains level and parallel at all times.
- Track supports must be stable and capable of supporting the loads imposed.
- Load must be uniformly distributed over the surface of the skid shoe. Do not point load. Do not exceed capacity (see capacity chart).
- Use only a proper hydraulic pump unit, fluids and hoses. Do not exceed 10,000psi.
- Ensure push cylinders extend in unison otherwise the shoes may jam and result in possible damage.
- Maintain skidding surfaces clean, dry and completely covered with graphite. Reapply graphite frequently depending on use and storage conditions.
- Repair or replace any broken, worn or damaged components.

**500 TON HYDRA SLIDE**

Location	 <b>PROFESSIONAL ENGINEERS</b>	37 ALLEN STREET WEST WATERLOO, ONTARIO CANADA N2L 1C9 tel (519) 746-6368 fax (519) 746-3529	SK. No.
Owner/Client			1
Project	Drawn by HH      Checked by RM      Project No. M1-525 Designed by HH      Date NOV. 2006      Scale 1/8"=1'-0		Sheet

**CAPACITY CHART**